



CMP-CHATPACK10  
CMP-WEBCAM11/15  
CMP-WEBCAM70/75/80/85



ENGLISH  
INSTRUCTIONS

### 1. Package contents

- USB Webcam
- Headset (for CMP-CHATPACK10 only)
- Manual
- Driver CD

### 2. System requirements

- Windows® 98SE / ME / 2000 / XP
- USB 1.1 or 2.0 Port
- CD-ROM drive for installation
- Pentium 1 GHz or higher
- 128 MB memory (256 MB recommended)
- 20 MB hard disk space
- 32 MB graphics card or above
- Soundcard

### 3. Driver installation

Insert the driver CD and wait for the software to start (if Autorun does not work on your system, please locate the setup.exe file manually and double click on it). Follow the instructions on the screen.

### 4. Hardware installation

#### Step 1:

Connect the USB webcam to the PC and let Windows detect the new hardware. Follow the instructions as shown on the screen. If you get a message box saying the driver has not been certified for use with Windows XP, please click Continue anyway to install the driver.

#### Step 2:

Start the software to begin capturing images from your webcam or use another application that supports the use of a webcam.

#### Step 3:

If you have purchased the CHATPACK10, then you need to connect the headset to the proper connections of your sound card. Refer to the manual of your computer or sound card if you are unsure which connections to plug in the headset.

### Safety precautions:

To reduce risk of electric shock, this product should ONLY be opened by an authorized technician if service is required. Disconnect the product from mains and other equipment if a problem should occur.

### Warranty:

No guarantee or liability can be accepted for any changes and modifications of the product or damage caused due to incorrect use of this product.

### General:

Designs and specifications are subject to change without notice.